

3 HOLE POSITIONS

THANKYOU FOR PURCHASING THE WILLWORX "FAT RACK" BICYCLE STAND ASSEMBLY INSTRUCTIONS

- (1) Loosely screw the two curved tubing pieces to the front base leg with 2 long M6 screws.
- (2) Loosely fit and screw the short cross pieces between the two bent rails with 2 x M6 screws.
- (3) Loosely screw the rear base leg to the bottom rear of the 2 bent rails with the 2 x M5 screws.
- (4) Tighten all of the base screws.
THE SUPERSTAND MAY ASSEMBLE SLIGHTLY CROOKED -- DO NOT WORRY.
- (5) Fit the top hoop tubes to the swaged sections of the base & twist the frame until the buttons & holes at the back of the uprights line up & lock.
- (6) Adjust the "FAT RACK" to suit the width of your tire using the different holes in the base legs and holes at the top of the hoop.
- (7) Push the rubber feet onto each leg end.
- (8) Square-up the stand on a flat surface & re-tighten all of the screws.

**YOUR SUPERSTAND "FAT RACK"
IS NOW READY TO USE.**

**Simply wheel your bike into the stand
with either the front OR rear wheel.**

Buttons at back
of tubing

2 x M5 x 35L SCREWS

2 x M6 x 35L
SCREWS

ADJUSTABLE WIDTH INCREMENTS

Inner 2 holes for 4.25"

One inner & 1 outer hole for 4.75"

Outer 2 holes for 5.25"

2 x M6 x 35L
SCREWS

